

Overview

These installation instructions are intended for securing Hydraway to its fittings with HydraTape.

Installation

1. Slide the fitting onto the end of Hydraway (See Notes).
2. Hold the fitting and Hydraway in place.
3. Using HydraTape, secure the fitting to Hydraway by taping completely around the product. The tape should cover 5-6 inches over the seam of the product.
4. Cut HydraTape with a knife or scissors.

Notes

When securing Hydraway to a splice fitting, it is inserted halfway into the splice fitting and then secured with HydraTape. The additional piece of Hydraway is then inserted into the other side of the fitting and secured the same way.

When securing Hydraway to all other fittings, it is inserted all the way into the fitting until it hits the internal plastic.

